

GXE5028 Voice Prompt Definition
Version 2.0

System Prompt Number (For GS internal tracking)	Speech Contents	Other Language
0	Zero	
1	One	
2	Two	
3	Three	
4	Four	
5	Five	
6	Six	
7	Seven	
8	Eight	
9	Nine	
12	The number you dialed cannot be reached at the moment; please try again later.	
13	The number you dialed is not available; please check and try again.	
14	The number you dialed is busy; please try again later.	
15	[two seconds of silence]	
16	The WAN IP address is...	
17	The LAN IP address is...	
18	Dot	
19	[ringback tone]	
21	The feature you request is now activated	
22	Sorry, the feature code operation failed.	
23	The feature code you entered is no longer available	
27	[music on hold]	
28	The IVR file number you are recording is	
29	The IVR file number you are playing is	

30	Number	
31	Please record the voice prompt. When done, hang up.	
32	Sorry, I can not record the sound.	
33	The IVR file does not exists.	
34	[call-waiting tone]	
35	[parked call music]	
36	Please wait.	
37	Sorry the parking number you entered is not valid, goodbye	
38	Unconditional call forward.	
39	Call forward on no-answer.	
40	Call forward on busy.	
41	Call forwarding condition is...	
42	The forward number is...	
43	Parked at	
100	Thank you for calling Grandstream Networks. Please dial your party's extension, or press zero for the operator.	
101	Please enter your pass code	
102	Wrong pass code; please enter again.	
103	There is no space for faxes.	
130	[personal greeting tone]	
131	[name tone]	
140	Begin faxing after the beep.	
141	[Fax CED tone]	
142	[Fax CNG tone]	
150	Sorry, the conference room is full.	
151	Your queue position is number...	
152	Transferring.	
200	Zero	
201	One	

202	Two	
203	Three	
204	Four	
205	Five	
206	Six	
207	Seven	
208	Eight	
209	Nine	
210	Ten	
211	Eleven	
212	Twelve	
213	Thirteen	
214	Fourteen	
215	Fifteen	
216	Sixteen	
217	Seventeen	
218	Eighteen	
219	Nineteen	
220	Twenty	
221	Twenty-one	
222	Twenty-two	
223	Twenty-three	
224	Twenty-four	
225	Twenty-five	
226	Twenty-six	
227	Twenty-seven	
228	Twenty-eight	
229	Twenty-nine	
230	Thirty	
231	Thirty-one	

232	Thirty-two	
233	Thirty-three	
234	Thirty-four	
235	Thirty-five	
236	Thirty-six	
237	Thirty-seven	
238	Thirty-eight	
239	Thirty-nine	
240	Forty	
241	Forty-one	
242	Forty-two	
243	Forty-three	
244	Forty-four	
245	Forty-five	
246	Forty-six	
247	Forty-seven	
248	Forty-eight	
249	Forty-nine	
250	Fifty	
251	Fifty-one	
252	Fifty-two	
253	Fifty-three	
254	Fifty-four	
255	Fifty-five	
256	Fifty-six	
257	Fifty-seven	
258	Fifty-eight	
259	Fifty-nine	
260	Sixty	
261	Sixty-one	

262	Sixty-two	
263	Sixty-three	
264	Sixty-four	
265	Sixty-five	
266	Sixty-six	
267	Sixty-seven	
268	Sixty-eight	
269	Sixty-nine	
270	Seventy	
271	Seventy-one	
272	Seventy-two	
273	Seventy-three	
274	Seventy-four	
275	Seventy-five	
276	Seventy-six	
277	Seventy-seven	
278	Seventy-eight	
279	Seventy-nine	
280	Eighty	
281	Eighty-one	
282	Eighty-two	
283	Eighty-three	
284	Eighty-four	
285	Eighty-five	
286	Eighty-six	
287	Eighty-seven	
288	Eighty-eight	
289	Eighty-nine	
290	Ninety	
291	Ninety-one	

292	Ninety-two	
293	Ninety-three	
294	Ninety-four	
295	Ninety-five	
296	Ninety-six	
297	Ninety-seven	
298	Ninety-eight	
299	Ninety-nine	
300	One-hundred	
301	Please leave your message after the tone. Press # when done. [beep]	
302	Press 1 to accept the message. Press 2 to listen, press 3 to re-record, or press 4 to cancel the message.	
303	Invalid entry.	
304	The recording is done.	
305	No more space for voicemail.	
306	Recording completed	
307	Operation cancelled.	
308	Please hang up.	
309	No entry detected.	
310	Please try again.	
311	[one second of silence]	
312	This is...	
313	Goodbye.	
314	Now joining the conference.	
330	January	
331	February	
332	March	
333	April	
334	May	
335	June	

336	July	
337	August	
338	September	
339	October	
340	November	
341	December	
350	Please enter the voicemail extension and #.	
351	That voicemail extension is invalid.	
353	Invalid password.	
354	You have	
355	and	
356	Received	
357	No messages.	
358	New message	
359	Old message	
360	Press 1 to listen.	
361	Press 2 for voicemail options.	
362	Press * for help	
363	Press # to exit.	
364	Press 1 for voicemail messages. You can listen, delete and undelete, and save messages. Saved messages will be stored for six months. Press 2 to configure voicemail box settings. You can record your name and personal greeting, and your password.	
365	Message	
366	No more messages.	
370	Press 1 to replay this message.	
371	Press 2 to play the previous message.	
372	Press 3 to play the next message.	
373	Press 4 to reply or forward this message.	
374	Press 7 to delete.	

375	Press 7 to un-delete.	
376	Press 8 to hear message details.	
377	Press 9 to save this message.	
378	Press 9 to un-save this message.	
380	Press # to return to the main menu.	
381	Press 1 to replay this message, press 5 to rewind 3 seconds, press 6 to fast-forward 3 seconds, or press # to stop message playback.	
382	Press 2 to play the previous message	
383	Press 3 to play the next message	
384	Press 4 to replay or forward this message	
385	Press 7 to delete	
386	Press 7 to undelete	
387	Press 8 to listen the message	
388	Press 9 to save this message	
389	Press 9 to un-save the message	
390	Press 1 to return the call.	
391	Press 2 to leave a voicemail for the caller.	
392	Press 3 to forward this message to another extension.	
396	Please hold while your call is connected	
397	Sorry, the caller's number was not sent. The call cannot be returned.	
398	Sorry, that mailbox does not exist or is full.	
399	Sorry, the caller does not have a mailbox or it is full.	
400	Press 1 to prepend a message, press 2 to forward this message without prepending, or press 3 to cancel.	
401	Message forwarded.	
402	Message deleted.	
403	Message un-deleted.	
405	Message marked for deletion.	

406	Old message.	
407	Message saved.	
408	From	
409	To	
410	Message un-saved.	
411	Message saved.	
412	Message save failed.	
413	Press 1 to record your personal greeting, press 2 to record your name, press 3 to change your password, press * for help, or press # to return to the main menu.	
414	Press 1 to record you personal greeting; callers will hear your personal greeting when reaching your voicemail box. Press 2 to record your name; callers will hear your name if you do not have a personal greeting. Press 3 to change your mailbox password.	
415	Please record after the beep. Press # when done.[beep]	
416	Please enter your new password.	
417	Please enter your new password again	
418	Your password has been changed.	
419	Password change failed.	
420	Operation failed, please hang up.	
421	Please record your name after the beep. Press # when done. [beep]	
423	On	
424	At	
425	Message Deleted	
426	Press one to leave voicemail	
427	Press two to send fax	

Note:

1. The microphone shall have enough gain to yield near full scale 16-bit waveform
2. The data shall be sampled at 8KHz, Mono.
3. The wave file should be saved as "SystemPromptNuber".wav, eg. 9.wav for recording "9".