

Grandstream Networks, Inc.

GXV3140 IP Multimedia Phone

GUI Customization Guide



TABLE OF CONTENTS

GXV3140 GUI CUSTOMIZATION GUIDE

INTRODUCTION	.1
OVERVIEW	1
HOW TO CUSTOMIZE GXV3140 LCD GUI	1
CONFIGURATION GUIDE	.2
APP SETTING	2
Add a GMI Application	3
LAYOUT SETTING	5
PHONEBOOK SETTING	6
ACCOUNT SETTING	7
SCREEN DISPLAY SETTING	8
MAINTENANCE SETTING	9

TABLE OF FIGURES

GXV3140 GUI CUSTOMIZATION GUIDE

Figure 1: App Setting Interface	2
Figure 2: App Setting \rightarrow Add a GMI Application	3
Figure 3: App Setting → GMI Application Example	4
Figure 4: Layout Setting Interface	5
Figure 5: Phonebook Setting Interface	6
Figure 6: Account Setting Interface	7
Figure 7: Screen Display Setting Interface	8
Figure 8: Maintenance Setting Interface	9



INTRODUCTION

OVERVIEW

Grandstream GXV3140 IP Multimedia Phone allows users to customize the GUI desktop layout as well as GUI configurations on the phone, offering users with flexibility and control. The GUI configuration includes display/hide certain applications, configure parameters on the phone with specific configuration items, control the display appearance and enable/disable some applications and much more.

This document describes how to use the Grandstream Graphical GUI Customization Tool to customize the GXV3140 GUI settings and applications. This tool allows users to do the following on applications running on GXV3140:

- Turn on/off applications
- Set up parameters
- Personalize phone display
- Turn on/off certain functions on applications

The Grandstream GXV31xx Graphical GUI Customization Tool is available for download from the following link: <u>GXV31xx GUI Customization Tool</u>.

HOW TO CUSTOMIZE GXV3140 LCD GUI

- 1. Unzip the tool package. Double click on "Grandstream VoIP Phone Config Tool.exe" to start up the tool. Single click on GXV3140 picture to get into the GXV3140 GUI customization interface.
- 2. Set up the parameters and application configurations.
- 3. Generate the GXV3140 custom file "gxv3140cust" by clicking on "File → Save As". The tool also allows users to read and edit the existing custom files.
- 4. Put the generated custom file "gxv3140cust" on your HTTP/TFTP/HTTPS server.
- 5. Point the phone's firmware upgrade path to the directory on the server where the custom file locates.
- 6. Reboot the phone to trigger the upgrade.
- 7. After booting up, GXV3140 LCD shall display the customized GUI.



CONFIGURATION GUIDE

APP SETTING

The following figure shows the "App Setting" section on the Config Tool.

randstream VoIP Phone Config Too	bl	-		
Edit Help Server Lang	uage			
🖻 🖯 🗢 🔊 🥥				
pp Setting Layout Setting	Phonebook Setting	Account Setting	Screen Display Setting	Maintenance Setting
Select	display-	name:		
Deneted phonebook	Propert	v: 🗆		
🛛 🕤 callhistory	name:			
 messages Socialnetwork 	icon:			
 webbrowser webbrowser multimedia 	Propert Path:	y: 🗆		Browse
 Ø application Ø 🥸 settings 	dynami Propert	c-icon:		
Image: Second	Path:			Browse
	other: hide:		🗆 yes	
	type: link-url:		normal	🔊 gmiapp



In this section, users could configure the following:

- Edit menu layout structure
- Enable or disable specific application
- Edit options to be displayed on GUI interface for a specific application, which includes icon and text for description purpose. (Default settings will be applied if there is no change made)
- Add submenu or link by right-clicking on the left panel list



Note:

On the left panel list, "Settings", "Callhistory" and "Phonebook" are mandatory.

Add a GMI Application

To add a GMI application, with the cursor located within the left panel, right-click the mouse, a drop-down menu will appear, with two options "add submenu" and "add link". Click on "add link", a pop-up window "AddLink" will be shown like the following. Browse and select an "Icon" and a "DynamicIcon", enter a "Display Name", and click on "Add".

Grandstream	VoIP Phone Config Too	bl			
le Edit H	elp Server Lang	luage			
	Þ 🥱 🥥				
pp Setting	Layout Setting	Phonebook Setting	Account Setting	Screen Display Setting	Maintenance Setting
Sele	ct	display	-name:		
	phonebook callhistory	Propert name:	ry: 🗆		
	messages socialnetwork webbrowser multimedia application	AddLink Icon: T DynamicIcon: F Display Name: F	P_ROOT/TMP3/about.png TP_ROOT/TMP3/Blue.jpg Hotel	P X3 Browse Browse Browse Browse	Browse
> v v v > v X V ()	personalize status	Propert Path:	ry: □		Browse
		hide: type: link-url:		□ yes ⊚ normal	O gmiapp

Figure 2: App Setting → Add a GMI Application

A Hotel application with the icon and display name shows up in the left panel. On the right panel,



display-name and icon are filled with the information entered previously. Under "other", users have the option to "hide". For "type", please select "gmiapp". For "link-url", users can enter file://sda1/Hotel/index.html for a local application. If it is a remote GMI application, users need to enter a HTTP URL like http://www.grandstream.com. For more details on the GXV3140 GMI Configuration, please refer to: GXV3140 GMI Guide

GXV3140 GMI Example

🚀 Grandstream VoIP Phone Config Too	bl				
File Edit Help Server Lang	uage				
🖻 🖯 🗢 🥱 🥥					
App Setting Layout Setting	Phonebook Setting	Account Setting	Screen Display Set	tting Maintenand	e Setting
Select	display-	name:			
🗵 🏫 Hotel	Propert	y: 🔽			
phonebook Gallbistory	name:	Hotel			
 	ricon:	у: 🔽			
🛛 🤕 webbrowser	Path:	Desktop/TFTP_	_ROOT/TMP3/about	t.png	Browse
 Image: Image: Ima	dynami	c-icon: y: ☑			
 Image: Settings Image: Image: Settings Image: Settings	Path:	Desktop/TFTP_	_ROOT/TMP3/Blue.j	ipg	Browse
🛛 🕡 status	other: hide:		🗆 yes		
	type: link-url:		normal file://sda1/Hotel/inc	gmiapp lex.html	

Figure 3: App Setting → GMI Application Example



LAYOUT SETTING

The following figure shows the "Layout Setting" section on the Config Tool. Users could customize the following for the GXV3140 desktop layout with either the "Big Layout" configuration or "Custom Layout" file.

Cotting	Loveut Settin	Dhanahaalt Catt			otting Mainta	nance Cetting
setting	Layout Settin	Phonebook Set	ang Account Setu	ig Screen Display S	etting Mainte	nance setting
		55 B	M			
	Big Layout	Custo	m Layout			
	-	DeskTop1	DeskTop2	DeskTop3	DeskTop4	
	Left Window	None -	None	None -	None	T
	Right Window	None -	None	None -	None	•
	F1	Menu -	Menu	Menu 👻	Menu	•
	F2	Switch Screen	Switch Screen	Switch Screen -	Switch Screen	•
	F3	None	None	None -	None	•
	F4	None -	None	None 🔻	None	-

Figure 4: Layout Setting Interface



PHONEBOOK SETTING

The following figure shows the "Phonebook Setting" section on the Config Tool. As can be seen, in this section, parameters for phonebook download such as Download Mode, URL and Update-Interval can be set up for the GXV3140.

Grandstream VoIP Phone File Edit Help Serve	Config Tool		_	-	00	X
🖻 🖯 🔶 🥱 🌘			10			
App Setting Layout	Setting Phoneb	ook Setting	Account Setting	Screen Display Setting	Maintenance Setting	
Do Cle Do Up	wnload ear The Old List: wnload Mode: wnload URL:	yes OFF 0	Replace Du	iplicate Items: 🗐 yes		

Figure 5: Phonebook Setting Interface



ACCOUNT SETTING

The following figure shows the "Account Setting" section on the Config Tool. Users could enter the account information here to register the account on GXV3140.

Edit Help Server Langu	Jage				
🖯 🗢 🥱 🥥					
Setting Layout Setting	Phonebook Setting	Account Setting	Screen Display Setting	Maintenance Setting	
ount					
🔏 Account 1	Account A	Active :			
🔏 Account 2					
🔏 Account 3	Account N	lame :			
	SIP Serve	r :			
	Outbound	Proxy :			
	SIP Auth	ID:			
	SIP Auth	PassWord:			
	SIP User	ID:			
	Display N	ame:			

Figure 6: Account Setting Interface



SCREEN DISPLAY SETTING

The following figure shows the "Screen Display Setting" section on the Config Tool. Users could customize the screen saver and background image on the idle screens for GXV3140.

Edit He	alp Server Langua	ige			
	• 🤊 🥥				
p Setting	Layout Setting P	Phonebook Setting	Account Setting	Screen Display Setting	Maintenance Setting
	Screen Saver:				
	Screen Saver:		Default Folde	r	•
	Interval(10~999 :	s):	10		
	Time Out (0~600	0000 s):	5		
	LCD Auto Power (Off Time (0~60000	0 s): 15		
	Background:				
	Desktop Backgrou	und: Default		*	
	Picture:			В	rowse
	Image Position:	Stretc	ch 🔍 WI	hole Tile 💿 Scale	Tile

Figure 7: Screen Display Setting Interface



MAINTENANCE SETTING

The following figure shows the "Maintenance Setting" section on the Config Tool. Users could select display languages, configure upgrade server, and choose "Lock" or "Hide" "factory reset" and "Firmware Config" on the LCD.

🚀 Grandstream VoIP Phone Config Too	bl					x
File Edit Help Server Lang	juage					
🖻 🖯 🗢 🥱 🥥						
App Setting Layout Setting	Phonebook Setting	Account Setting	Screen Displa	y Setting	Maintenance Setting	
Select Langu	Englis	h	•			
Select Langu	Lingis	11				
Language Do	ownload Mode: 💿 OFI	F © T	FTP	© HTTP		
Language Do	ownload Server:					
Factory Rese	et: 🔲 Loc	k 🔲 Hi	ide			
Firmware Co	nfiq: 📃 Loc	k 🔲 Hi	ide			
KTU ADA CAROL I DODARDA						
						.d

Figure 8: Maintenance Setting Interface